



Jump Ski Mounting Instructions

Recommended Binding Placement

The following measurements are from the tail of the ski to the leading edge of the binding heel horseshoe.

Please use a 7/64" drill bit to drill pilot holes 1/4" deep. **Do not drill any deeper.** You must be sure to go through the aluminum screw retention plate just under the top-skin of the ski. All screws used for mounting the binding **MUST** be in the screw retention plate. Failure to do this may create a weak point in the jumper and possibly cause it to break. This will not be covered under warranty. Always re-tighten your binding screws after the first couple uses.

68" Team Std Tip 27.25"

70" Team Std Tip 27.50"

72" Team Std Tip 27.75"

74" Team Std Tip 28.00"

76" Team Std Tip 28.25"

78" Team Std Tip 28.50"

80" Team Std Tip 28.75"

82" Nightmare 29.25"

84" Nightmare 29.50"

86" Nightmare 29.75"

88" Nightmare 30.00"

90" Nightmare 30.25"

92" Nightmare 30.50"

D3 SKIS, INC
3526 B Street NW, Suite 101
Auburn, WA 98001
Phone: (253) 508-0079
e-mail: info@d3skis.com
www.d3skis.com

